



River Raider Hi-Lift Jack Hood Mount

Thank you for purchasing a River Raider product. Our goal is to provide a quality product that makes your Jeep more capable, and your off-road experience more enjoyable.

1. PREP YOUR VEHICLE BY TAPING THE NUTS UNDERNEATH YOUR HOOD HINGE TO PREVENT THEM FROM FALLING INTO YOUR ENGINE COMPARTMENT WHILE REMOVING THE BOLTS.
2. REMOVE THE HOOD HINGE BOLTS FROM ONE HINGE AT A TIME AND SAVE THEM.
3. POSITION THE NEW HI-LIFT HOOD MOUNT BRACKET ON THE HINGE AND BOLT ON WITH YOUR FACTORY HARDWARE. (BE SURE TO USE LOCTITE ON THESE BOLTS TO KEEP THEM FROM WORKING LOOSE.) THEN REPEAT ON THE OTHER SIDE.
4. POSITION THE JACK ON THE MOUNTS AND ATTACH WITH THE SUPPLIED HARDWARE.
5. BE SURE TO FULLY SECURE THE JACK BY TIGHTENING DOWN THE WING NUTS ONTO THE LOCK WASHERS AND FLAT WASHERS.

IT IS THE VEHICLE OWNER'S RESPONSIBILITY TO ENSURE THE SAFE USE OF THIS HI-LIFT MOUNT. ALWAYS MAKE SURE THE JACK AND ALL ITS PARTS ARE FULLY SECURED AND THAT THE HARDWARE IS TIGHT.