

Gen 3 Outlander Rear Rack Instructions

Step 1 – Start by using a ¼” drill bit to drill holes in the bottom of the pelican case.

Step 2 – Use the provided bolts to attach the pelican case to the metal holder as shown in photos. Pay attention to which way its facing as it is narrower in the front, and wider in the back just slightly

Step 3 – Once the case is secure, remove the factory hardware from all 4 holes and place it on the front two holes. Use the M6 1.0 Bolts to secure the metal case holder, and the upright supports marked L and R.

Step 4 – Line up the rear holes, and use factory hardware to secure the rear portion of the upright supports.

Step 5 – Use the 10 colored bolts and nuts included, to secure the rack to the upright supports.















