

Can Am Gen 2 Metal Rear Rack Replacement Instructions

1. Remove factory metal rack. You'll need a T25, and T27 Torx Bit, 13MM Wrench. For Install you will need a 4mm Allen Wrench, and open end 10mm wrench in addition to the other tools.
2. Start installing the Lucky 7 Rack by inserting the small black brackets from the top down, and tab facing towards you (Photo 2). Refer to photo 3 for the next step.
3. Start the bolts mounting the bracket to the frame by hand (DO NOT TIGHTEN YET) You can bolt down, and tighten the 4 bolts surrounding the factory storage box,
4. As shown in photo 6 and 7, Use the M6x70MM Bolt, and spacer to attach the rack to the rear plastics.
5. Attach the Rear supports to the frame using factory hardware, and the included colored M6 Bolts and nuts in the hardware kit.
6. Tighten all hardware except the lower bolts on the front L shaped brackets. These holes are slotted for adjustability, so move the plastics where you want them, and use a 13mm wrench or socket to tighten the brackets to the frame.

















