

Brute Force Rear Rack Installation Instructions

Parts

(2) M10x85mm Button Head Bolts with 1-3/8" Black Round Spacer

(2) M10x30mm Button Head Bolts

(2) M6x70mm Bolts with 1" Spacers, washer, and nut

Step 1: Remove Factory Rear Rack.

Step 2: Using the first photo for reference, Place the 1-3/8" round spacers on top of the metal rack spacer at the front of the rack, next to the seat.

Step 3: Set the shorter 1" spacer on the hole in the fenders on the left and right side. If it looks like it does in the first photo, You're ready to set the rack on top.

Step 4: Using the long M10x85mm Bolts, go through the front two holes on the rack, through the spacer, and into the factory mounting location. Hand tighten for now.

Step 5: Using the shorter M10x30mm Bolts, go through the rear two holes on the rack, into the factory mounting location. Hand tighten for now

Step 6: Using the M6x70 bolts, go through the rack, and through the spacer and factory plastics. Use the washer and nut on the other side. Tighten bolts.

Step 7: Tighten the larger hardware, and check that every bolt is tight, and everything is aligned.













