

Kodiak 450 Front Rack Installation Instructions0

See Picture 1 below for parts reference

(2) Front Bolts M8 x40MM paired with 1” Spacers

(2) Side bolts for mounting through plastics – M6x70mm Bolts 1-7/8” Spacers, Fender Washer and nut

(4) Colored Bolts M6 and lock nuts, used for rear mounting of rack to the included Z shaped brackers

Step 1- Remove Factory Front Rack, and keep hardware, as you’ll reuse 2 of the bolts to attach the Z shaped mounting brackets to the 4 wheeler before setting the rack down.

Step 2 – Attach the Z shaped bracket to the 4 wheeler using factory hardware. Single hole goes down, and the double holes go up. The double holes will be used to attach to the rack using the colored hardware. You can tighten this at any point, but recommended to get all hardware in place and tighten once in place and complete.

Step 3 - Using the short 1” spacer, set the spacers on the two front mounting points, and use the included M8x40mm through the rack and spacer to mount to the factory mounting point. Tighten Bolt.

Step 4 – Using the long 1-7/8” spacer, and M6x70mm bolt, put the bolt down through the rack, and spacer goes on top of the plastics. The fender washer and nut go on the bottom side of the plastics. Tighten Bolt and nut.

There are photos of every angle where the hardware mounts, and the first picture will show where each set of hardware is mounted in relation to the rack.

Let us know if you have any questions.















