

Kodiak 450 Rear Rack Instructions

Parts

- (2) Front Mounting brackets (Z shape with one hole on bottom, two holes on top)
- (2) Rear Mounting brackets (Z shape, Bottom is rounded, top is square)
- (2) M6x70mm Bolts with 1-7/8" Spacers, fender washer and nut
- (6) Colored bolts with nuts, used for attaching rack to Z shaped brackets

Step 1- Remove factory rear rack, and hold on to mounting hardware, as you will reuse it. Refer to first photo showing location of Z shaped brackets. Install Z shaped brackets using factory hardware.

Step 2 – Use included colored bolts and nuts to attach rack to the Z shaped brackets. Suggest leaving all hardware snug, but not tight until all parts are installed and lined up.

Step 3 – Using the long M6 Bolts, Put bolt through rack, into spacer, and through fender hole. Photos for reference, but the spacer goes between the bottom of your new rack, and the fenders. Once the bolt is through, use the fender washer and nut to tighten.

Step 4 – Tighten All hardware

















