

Highlifter 850/1000 Radiator Relocate Cover Instructions

1. Remove factory plastic radiator cover.
2. Using the Lucky 7 Cover as a template, set the cover on the 4 wheeler. Mark and Drill 4 holes along sides. Front holes do not need drilled.
3. Remove Front Bumper (fascia) to gain access to tighten nuts.
4. Carefully replace bumper while tucking underneath the rad cover, replace bolts holding front bumper.
5. Using included bolts, and fender washers, attach the front 2 bolts. You can reach up in the wheel wells to hold the nut with a wrench.
6. Tighten everything down.
7. If you purchased the cover with the speakers, amp, & bluetooth controler. You will use the 4 small bolts that come installed in the cover to mount the amp.
8. The only thing not included is the power wire from your battery, or switch, and connectors. We recommend heat shrink butt connectors. Run a decent 14 guage or bigger wire up, and power the amp and bluetooth controller with it. There is a photo showing the single power wire being split to two different pairs of power. Make sure the bluetooth controller Positive (red) and Yellow wires are both going to power, both blacks to negative. The blue remote wire from the blueooth controller connects to the blue remote wire on the amp.
9. The speakers connect to the amp, just make sure your + wire and – wire match from the amp wiring to the speakers.













